








# APPLICATION GUIDE

## 2011

Model	Year	Notes	Front kit	Type	Airspring	Rear Kit	Type	Airspring	
<b>Audi</b>									
A6	98-07					4105	C/R	6013	
<b>Chrysler</b>									
PT Cruiser	01-11					4139	C/R	6015	
Voyager	08-11					4169	C/R	6013	
Voyager	96-07					1005	L/R	7217	
<b>Citroen</b>									
Berlingo C4	08-11	Electronic Height Control-With Lowering				3168	F/A	9000	
C25-Euro Chassis 280/290	88-93	All Applications +				2112	S/A	6781	
C8	02-11	Electronic Height Control-With Lowering				3516	F/A	9017	
Dispatch-Jumpy	96-06					4143	C/R	6016	
Dispatch-G9	07-11					4264	C/R	6016	
		Electronic Height Control-With Lowering (Not Suitable for SWB)				3496	F/A	9934	
Jumper/Relay-Euro Chasis X230/X244	94-06	All Applications +				2110	S/A	6781	
Jumper/Relay Euro Chassis X250	06-11	Standard Kit to Suit all Applications-ABS Vehicles Only				2428	S/A	6781	
		Larger Springs(For Extra Comfort) ABS Vehicles Only				2429	S/A	7339	
		Driverite Comfort Improvement Kit				3202	F/A	9934	
		4 Corner-Electronic Height Control-With Lowering		3205	F/A	9932	3205	F/A	9931
		Electronic Height Control-With Lowering					3337	F/A	9931

*Notes:*

*+ =Load Sensing Valve kits available-Contact Drive-Rite for further details*

Model	Year	Notes	Front kit	Type	Airspring	Rear Kit	Type	Airspring
<b>Diahatsu</b>								
Rocky	00-07					4580	C/R	4580
<b>Fiat</b>								
Doblo	10-11					4249	C/R	6021
Doblo	10-11	Electronic Height Control-With Lowering 				3517	F/A	9000
Ducato Euro Chassis 280/290	88-93	All Applications +				2112	S/A	6781
Ducato Euro Chassis X230/X244	94-06	All Applications +				2110	S/A	6781
Ducato Euro Chassis X250	06-11	Standard Kit to Suit all Applications-ABS Vehicles Only				2428	S/A	6781
		Larger Springs(For Extra Comfort) ABS Vehicles Only				2429	S/A	7339
		Driverite Comfort Improvement Kit				3202	F/A	9934
		4 Corner-Electronic Height Control-With Lowering 	3205	F/A	9932	3205	F/A	9931
		Electronic Height Control-With Lowering 				3337	F/A	9931
Scudo	96-06					4143	C/R	6016
Scudo G9	07-11					4264	C/R	6016
		Electronic Height Control-With Lowering (Not Suitable for SWB) 				3496	F/A	9934
Ulysse	02-11	Electronic Height Control-With Lowering 				3516	F/A	9017
<b>Ford</b>								
Ranger	00-11	4x4-For Vehicles Fitted with ABS				3454	S/A	6781
Transit 100/120	89-99	Square axle without Anti Roll Bar +				2123	S/A	6859
Transit 130/160/190	89-99	Round axle without Anti Roll Bar +				3001	S/A	6859
Transit	00-03	Square axle Single Rear Wheel- ABS Vehicles Only				3450	S/A	6781
		Round Axle Single Rear Wheel-ABS Vehicles Only				3451	S/A	6781
Transit	04-11	Square Rear Axle /Front Wheel Drive- Type 330-350 ABS Vehicles Only				3446	S/A	6397
		Square Rear Axle /Front Wheel Drive- Type 260-300 ABS Vehicles Only				3449	S/A	6397
Transit	00-11	Round Axle/ Dual Rear Wheel ABS Vehicles Only				3448	S/A	6781
Transit FT350	04-11	Round Axle/Rear Wheel Drive -ABS Vehicles Only				3447	S/A	6397
Transit Connect	02-11					3444	S/A	6781
<b>Honda Vans</b>								
Odyssey	05-11					4179	C/R	6020
Odyssey	99-04					4138	C/R	6017
Odyssey	96-98					4133	C/R	6018
<b>Honda SUVs</b>								
Passport	98-02	4x2, 4x4				4136	C/R	6014
Pilot	05-11					4179	C/R	6020
Pilot	01-04					4138	C/R	6017

*Notes:*

*+ =Load Sensing Valve kits available-Contact Drive-Rite for further details*

Model	Year	Notes	Front kit	Type	Airspring	Rear Kit	Type	Airspring
<b>Hummer SUVs</b>								
H3, H3T, H3X, HS Alpha	06-09					2460	S/A	6781
H2, H2 sut (With Rear Coil Springs)	03-09					4108	C/R	6003
<b>Hyundai Cars</b>								
Accent	07-09					4136	C/R	6014
<b>Hyundai SUVs</b>								
Santa Fe	07-11					4170	C/R	6017
Santa Fe	01-06					4167	C/R	6027
Veracruz	07-09					4170	C/R	6017
<b>Hyundai Vans</b>								
Entourage	07-09					4138	C/R	6017
<b>Isuzu</b>								
Amigo	98-00					4103	C/R	6014
Axiom	02-03					4136	C/R	6014
D-Max Rodeo	03-11	4x4 Leaf Spring Vehicle With ABS				3460	S/A	6781
NPR	96-11		2440	S/A	6868			
NQR	96-11	For Vehicles with ABS +				3407	S/A	5310
Oasis	96-98					4133	C/R	6018
Rodeo,Rodeo Sport	98-04					4136	C/R	6014
Trooper	98-02	4x4 Leaf Spring Vehicle With ABS				3460	S/A	6781
Trooper	98-04					4143	C/R	6016
Trooper	92-07					4106	C/R	6015
<b>Iveco</b>								
Daily 34-10, 35-12, 45-10, 45-12	90-99	Light Duty Application +				2089	S/A	6789
Daily 35-10 to 49-12	90-99	All Applications-Twin Rear Wheel (With ABS)-4 Bag System				3455	S/A	9000
Daily 35C-11 to 35C-13	00-06	Twin Rear Wheel (With ABS)-4 Bag System				3456	S/A	9000
Daily 35C to 50C	06-11	Twin Rear Wheel (With ABS)				3410	S/A	6859
Daily 50C-13	00-06	Twin Rear wheel (With ABS)-4 bag system				3456	S/A	9000
Daily 40C-13	00-06	Twin Rear wheel (With ABS)-4 bag system				3456	S/A	9000
Daily 35S-L 11 to 17	00-06	Single Rear Wheel (Leaf Below Axle)				3438	S/A	6784
Daily 29-35 S-L 11 to 18	00-11	Single Rear Wheel (Leaf Above Axle)				3439	S/A	6397
Daily 50 C	06-11	Electronic Height Control-With Lowering				3323	F/A	5399
Daily 60 C	06-11	Electronic Height Control-With Lowering	3322	F/A	7887			
Daily 60 C	06-11	Electronic Height Control-With Lowering				3324	F/A	8599




**Notes:**

+ =Load Sensing Valve kits available-Contact Drive-Rite for further details

Model	Year	Notes	Front kit	Type	Airspring	Rear Kit	Type	Airspring
<b>Jeep</b>								
Commander	06-09	4x2, 4x4				4157	C/R	6005
Grand Cherokee	11	4x2, 4x4				4184	C/R	6025
Grand Cherokee	05-10	4x2, 4x4				4157	C/R	6005
Grand Cherokee	92-98	4x2, 4x4 (Not "up country")				4118	C/R	6018
Grand Wagoneer	92-98	4x2, 4x4				4118	C/R	6018
Liberty	08-11	4x2, 4x4				4170	C/R	6017
Liberty	02-07	4x2, 4x4				4146	C/R	6005
Summit	92-93	SW Only				4105	C/R	6013
Wrangler Mountain	11	4x4 Only				4173	C/R	6006
Wrangler Rubicon	07-11	4x4 Only				4172	C/R	6007
Wrangler Sahara	07-11	4x2, 4x4				4173	C/R	6006
Wrangler Sport	10-11	4x4 Only				4173	C/R	6006
Wrangler X	07-09	4x2, 4x4				4173	C/R	6006
Wrangler Unlimited Mountain	11	4x4 Only				4173	C/R	6006
Wrangler Unlimited Rubicon	07-10	4x4 Only				4172	C/R	6007
Wrangler Unlimited Sahara	07-11	4x2, 4x4				4173	C/R	6006
Wrangler Unlimited Sport	10-11	4x2, 4x4				4173	C/R	6006
Wrangler Unlimited X	07-09	4x2, 4x4				4173	C/R	6006
Wrangler	97-06	4x2, 4x4				4157	C/R	6005
<b>Kia Vans</b>								
Sodana	06-11					4138	C/R	6017
<b>Kia SUVs</b>								
Sorento	03-08					4153	C/R	6024
<b>Land Rover</b>								
Defender 90	90-97					4121	C/R	6003
Defender 110	83-11					4510	C/R	6010
Discovery	90-04					4121	C/R	6003
Range Rover	90-96					4121	C/R	6003
Range Rover 93 MY, HSE 97MY	95-02	OEM-Original Landrover Suspension- Replacement Bags	OEM	F/A	0200	OEM	F/A	0027
<b>Lexus</b>								
LX 450	96-98					4124	C/R	6007
LX 470	99-11					4124	C/R	6007



*Notes:*

*+ =Load Sensing Valve kits available-Contact Drive-Rite for further details*

Model	Year	Notes	Front kit	Type	Airspring	Rear Kit	Type	Airspring
<b>Mazda</b>								
626	79-82					4591	C/R	6591
B2500/BT-50	00-11	4X4 For Vehicles Fitted with ABS				3454	S/A	6781
Mazda 5	06-11					4168	C/R	6027
Mazda 6	06-11					4168	C/R	6027
MPV	05-06					4140	C/R	6018
MPV Van	96-98					4105	C/R	6013
Pickup	72-90	4x2				1130	S/A	6859
<b>Mercedes</b>								
3 Series Sprinter 207-310	88-96	For All Applications				3004	S/A	6781
3 Series Sprinter 308,310,312,313,316	96-06	Motorhome Applications				3114	S/A	9000
		All Applications				2312	S/A	9002
Sprinter 209,211,213,215	06-11	ABS Vehicles Only (Excluding rear overhangs greater than 2 meters)				3500	S/A	6397
		Electronic Height Control-With Lowering 				3345	F/A	9931
Sprinter 309, 311,313, 315, 318, 324	06-11	ABS Vehicles Only (Excluding rear overhangs greater than 2 meters)				3500	S/A	6397
		ABS Vehicles Only/ All Applications				3502	S/A	6781
		Electronic Height Control-With Lowering 				3345	F/A	9931
4 Series Sprinter-408,410,412,413,416	96-06	Chassis Cab Version (Using 70mm Sleeve Airsprings)				3119	S/A	7095
		Chassis Cab Version (Using Double Convolute Airsprings)				2382	S/A	6397
		Van Version (Using 70mm Sleeve Airsprings)				3461	S/A	7095
		Van Version (Using Double Convolute Airsprings)				2425	S/A	6397
Sprinter 509,511,515,518,524	06-11	ABS Vehicles Only				3501	S/A	6859
		Kit with Larger Air Springs for Extra Volume and Comfort (ABS Vehicles Only)				4000	S/A	7339
		Electronic Height Control-With Lowering 				3346	F/A	5269
6 Series Sprinter-616	96-06	4 Bag System				3466	S/A	6781
Vito	96-03	Front Wheel Drive Vehicle				4145	C/R	6028
Vito	03-11	Rear Axle Only c/w Shock Absorbers (No Controls)				3489	F/A	9041
		Rear Wheel Drive Applications				4261	C/R	6016
<b>Mitsubishi</b>								
Expo	92-93					4105	C/R	6013
L200	90-05	4x4 For Vehicles Fitted With ABS				3457	S/A	6781
L200/Triton Warrior	06-11	4X4 For Vehicles Fitted with ABS				3469	S/A	6781
Montero Sport	99-04					4137	C/R	6007
Pajero/Shogun	93-03					4113	C/R	6007
Pajero/Shogun	04-11					4247	C/R	6014
Pickup	69-96	4x2				1130	S/A	6859







*Notes:*

*+ =Load Sensing Valve kits available-Contact Drive-Rite for further details*

Model	Year	Notes	Front kit	Type	Airspring	Rear Kit	Type	Airspring
<b>Nissan Cars</b>								
Altima	05-10					4105	C/R	6013
Maxima	05-08					4105	C/R	6013
<b>Nissan Vans</b>								
Atleon LP2 35.15-35HD,15-56,15	06-11					3406	S/A	6784
Atleon LG1 70.14-80,14-80.19	06-11	Auto Levelling Kit				3371	S/A	6183
		Manual Inflation Kit				3372	S/A	6183
		Compressor and Dual Gauge Kit				3373	S/A	6183
		Compressor and Single Gauge Kit				3374	S/A	6183
Cabstar	06-11	3.5 Tonne				3127	S/A	6784
Interstar X70	98-09	Heavy Duty+	4117	C/R	6004	3123	S/A	6784
		Complete Kit with Automatic Height Control +	4117	C/R	6004	3121	S/A	9000
		Tapered Sleeve Comfort Kit +	4117	C/R	6004	3126	S/A	9000
		Front Axle only (No Controls)	3382	F/A	2119			
		Driverite Comfort Improvement Kit	4117	C/R	6004	3141	F/A	9931
Interstar X62	10-11	ABS Vehicles Only (Rear Wheel Drive/Single Rear Wheel)				3117	S/A	6781
		ABS Vehicles Only (Front Wheel Drive/Single Rear Wheel)				3120	S/A	6397
Primastar X83	01-11					4250	C/R	6021
		Rear Axle Only c/w Shock Absorbers (No Controls) +				3465	F/A	9041
		Electronic Height Control-No Lowering +				3244	F/A	9041
		Electronic Height Control-With Lowering + 				3166	F/A	9041
Quest	04-09					4118	C/R	6018
Kubistar	08-11	Electronic Height Control-With Lowering 				3167	F/A	9000
<b>Nissan SUVs</b>								
Armada	06-10	4x2/4x4				4150	C/R	6023
Murano	09	4x2/4x4				4118	C/R	6018
Murano	03-08	4x2/4x4				4181	C/R	6024
Pathfinder Armada	04-05	4x2/4x4				4150	C/R	6023
Pathfinder	87-95	4x2/4x4				4106	C/R	6015
Pathfinder	06-10	4x2/4x4				4166	C/R	6021
Patrol	88-94	Leaf Spring 4x2				1130	S/A	6859
Patrol	93-11					4570	C/R	6010
Rogue	08-11	4x2/4x4				4181	C/R	6024
Xterra	05-11	4x2/4x4				2409	S/A	9002

*Notes:*

*+ =Load Sensing Valve kits available-Contact Drive-Rite for further details*

Model	Year	Notes	Front kit	Type	Airspring	Rear Kit	Type	Airspring
<b>Nissan Pickup Trucks</b>								
D21,D22, Navara	98-04	4X4 For Vehicles Fitted with ABS				3458	S/A	6781
D40, Navara	05-11	4X4 For Vehicles Fitted with ABS				2413	S/A	6397
Frontier	01-04	4x2				2293	S/A	9002
Frontier	05-11	4x2/4x4				2403	S/A	6766
Pickup	69-96	4x2				1130	S/A	6859
Titan	04-10	4x2/4x4				2355	S/A	6781
<b>Opel</b>								
Campo	88-02	4x4 Campo Fitted with ABS				3460	S/A	6781
Movano X70	98-09	Heavy Duty +	4117	C/R	6004	3123	S/A	6784
		Complete With Automatic Height Control +	4117	C/R	6004	3121	S/A	9000
		Tapered Sleeve Comfort Kit +	4117	C/R	6004	3126	S/A	9000
		Front Axle only (No Controls)	3382	F/A	2119			
		Driverite Comfort Improvement Kit	4117	C/R	6004	3141	F/A	9931
Movano X62	10-11	ABS Vehicles Only (Rear Wheel Drive/Single Rear Wheel)				3117	S/A	6781
		ABS Vehicles Only (Front Wheel Drive/Single Rear Wheel)				3120	S/A	6397
Vivaro X83	01-11					4250	C/R	6021
		Rear Axle Only c/w Shock Absorbers (No Controls) +				3465	F/A	9041
		Electronic Height Control-No Lowering +				3244	F/A	9041
		Electronic Height Control-With Lowering + 				3166	F/A	9041
<b>Peugeot</b>								
307	04-11					4158	C/R	6262
807	02-11	Electronic Height Control-With Lowering 				3516	F/A	9936
Boxer-Euro Chassis 280/290	88-93	All Applications +				2112	S/A	6781
Boxer-Euro Chassis X230/X244	94-06	All Applications +				2110	S/A	6781
Boxer Euro Chassis X250	06-11	Standard Kit to Suit all Applications-ABS Vehicles Only				2428	S/A	6781
		Larger Springs(For Extra Comfort) ABS Vehicles Only				2429	S/A	7339
		Driverite Comfort Improvement Kit				3202	F/A	9934
		4 Corner-Electronic Height Control-With Lowering 	3205	F/A	9932	3205	F/A	9931
		Electronic Height Control-With Lowering 				3337	F/A	9931
Expert	96-06					4143	C/R	6016
Expert G9	07-11					4264	C/R	6016
		Electronic Height Control-With Lowering (Not Suitable for SWB) 				3496	F/A	9934
J5-Euro Chassis 280/290	88-93	All Applications +				2112	S/A	6781
Partner	08-11	Electronic Height Control-With Lowering 				3168	F/A	9000

**Notes:**

+ =Load Sensing Valve kits available-Contact Drive-Rite for further details

Model	Year	Notes	Front kit	Type	Airspring	Rear Kit	Type	Airspring
<b>Renault</b>								
Espace	00-02					4251	C/R	6017
Espace	03-11					4250	C/R	6021
		Rear Axle Only c/w Shock Absorbers (No Controls)				3172	F/A	9931
Kangoo X61	08-11	Electronic Height Control-With Lowering 				3167	F/A	9000
Laguna II	02-03					4106	C/R	6015
Mascot	05-11					3125	S/A	6784
Master X70	98-09	Heavy Duty Kit +	4117	C/R	6004	3123	S/A	6784
		Complete with Automatic Height Control +	4117	C/R	6004	3121	S/A	9000
		Tapered Sleeve Kit +	4117	C/R	6004	3126	S/A	9000
		Front Axle only (No Controls)	3382	F/A	2119			
		Driverite Improvement Comfort Kit	4117	C/R	6004	3141	F/A	9931
Master X62	10-11	ABS Vehicles Only (Rear Wheel Drive)				3117	S/A	6781
		ABS Vehicles Only (Front Wheel Drive/Single Rear Wheel)				3120	S/A	6397
Maxity	07-11	3.5 Tonne				3127	S/A	6784
Maxity	07-11	4.5 Tonne*				3133	S/A	6784
Trafic X83	01-11					4250	C/R	6021
		Rear Axle Only c/w shock absorbers (No Controls) +				3465	F/A	9041
		Electronic Height Control-No Lowering +				3244	F/A	9041
		Electronic Height Control-With Lowering + 				3166	F/A	9041
<b>Ssangyong SUVs</b>								
Musso Sport	04-06					4240	C/R	6015
Musso Wagon	92-06					4241	C/R	6024
Rexton/Actyon	02-09					4103	C/R	6014
<b>Suzuki</b>								
Jimny	98-11		4515	C/R	4515	4516	C/R	4516
Sidekick	89-93					4620	C/R	3624
Vitara	90-00					4260	C/R	3624
<b>Toyota Cars</b>								
Echo	01-05					4118	C/R	6018
Yaris	07-10					4136	C/R	6014
<b>Toyota</b>								
4 Runner	90-95					4112	C/R	6006
4 Runner	96-97					4123	C/R	6021
4 Runner	98-08					4135	C/R	6024
Dyna 150	02-11	Dual Rear Wheel Only				3128	S/A	6859





*Notes:*

*+ =Load Sensing Valve kits available-Contact Drive-Rite for further details*

Model	Year	Notes	Front kit	Type	Airspring	Rear Kit	Type	Airspring
<b>Toyota (Cont.)</b>								
FJ Cruiser	07-11					4135	C/R	6024
Hiace	99-02					4500	C/R	6020
Hiace	03-11					4138	C/R	6017
Hilux	88-05	4x4 N16/N17 For Vehicles Fitted Wit ABS				3459	S/A	6781
Hilux/Vigo	06-11	4x4 +				3475	S/A	6859
Landcruiser	91-11	European Model				4124	C/R	6007
Landcruiser 100 Series	98-07					4114	C/R	6008
Landcruiser 200 Series	07-11					4129	C/R	6010
Landcruiser	88-96	Leaf Spring Vehicle-Bj75 Pick up				1130	S/A	6859
Pickup	69-95	4x2				1130	S/A	6859
Pickup	84-95	4x4				2116	S/A	6781
Rav 4	96-98					4104	C/R	6012
Sequoia	08-10					4164	C/R	6009
Sequoia	01-07					4124	C/R	6007
Siena	04-11	(Not AWD)				4155	C/R	6020
Siena	98-03					4118	C/R	6018
T100	93-98	4x2				2115	S/A	6781
		4x4				2116	S/A	6781
Tacoma	94-04	4x2				2213	S/A	6959
Tacoma TRD Prerunner	05-11	4x2 only				2407	S/A	6781
Tacoma	05-11	4x2				2410	S/A	6959
Tacoma	95-04	4x4				2304	S/A	6781
Tacoma Prerunner	05-09	4x2 only				2407	S/A	6781
Tacoma Prerunner	95-04	4x2 only				2304	S/A	6781
Tundra	07-11	4x2, 4x4				2445	S/A	6397
Tundra	00-06	4x2 only				2212	S/A	9001
		4x2 only				2245	S/A	6781
		TRD 4x2 only				2245	S/A	6781
Van With Rear Coils	64-89					4112	C/R	6006
<b>Vauxhall</b>								
Movano X 70	98-09	Heavy Duty +	4117	C/R	6004	3123	S/A	6784
		Complete With Automatic Height Control +	4117	C/R	6004	3121	S/A	9000
		Rear Axle Only Tapered Sleeve +	4117	C/R	6004	3126	S/A	9000
		Front Axle only (No Controls)	3382	F/A	2119			
		Driverite Comfort Improvement Kit	4117	C/R	6004	3141	F/A	9931




*Notes:*

*+ =Load Sensing Valve kits available-Contact Drive-Rite for further details*

Model	Year	Notes	Front kit	Type	Airspring	Rear Kit	Type	Airspring
Vauxhall (cont.)								
Movano X62	10-11	ABS Vehicles Only (Rear Wheel Drive/Single Rear Wheel)				3117	S/A	6781
		ABS Vehicles Only (Front Wheel Drive/Single Rear Wheel)				3120	S/A	6397
Vivaro X 83	01-11					4250	C/R	6021
		Rear Axle Only c/w Shock Absorbers (No Controls) +				3465	F/A	9041
		Electronic Height Control-No Lowering +				3244	F/A	9041
		Electronic Height Control-With Lowering + 				3166	F/A	9041
Volkswagen								
CC	09-11					4176	C/R	6027
Eos	07-11					4176	C/R	6027
GTI	07-11					4176	C/R	6027
Golf TDI	07-11					4176	C/R	6027
Jetta	07-10					4175	C/R	6026
Jetta Sport Wagon	09-10					4176	C/R	6027
Passat	98-06					4147	C/R	6024
Passat Wagon	07-09					4175	C/R	6026
Amarok	10-11					3129	S/A	6781
3 Series LT	96-06	Chassis Cab/Motorhome Application				3114	S/A	9000
		All Applications				2312	S/A	9002
4 Series LT	96-06	Chassis Cab Version (Using 70mm Sleeve Airsprings)				3119	S/A	7095
		Chassis Cab Version (Using Double Convolute Airsprings)				2382	S/A	6397
		Van Version Using Double Convolute Airsprings				2425	S/A	6397
		Van Version Using 70mm Sleeve Airsprings				3461	S/A	7095
Caddy	05-11	ABS Vehicles Only				3503	S/A	6781
Crafter 28-35	06-11	ABS Vehicles Only (Excluding rear overhangs greater than 2 meters)				3500	S/A	6397
		ABS Vehicles Only/ All Applications				3502	S/A	6781
Crafter 50	06-11	Kit with Larger Air Springs for Extra Volume and Comfort (ABS Vehicles Only)				4000	S/A	7339
		ABS Vehicles Only				3501	S/A	6859
Euro Van T-4	85-03					4117	C/R	6004
		Rear Axle Kit Only (No Controls)				3022	F/A	6988
Taro 4x4	88-04	N16/N17- For Vehicles fitted with ABS Only				3459	S/A	6781
Tiguan	09-11					4176	C/R	6027
T5 Van/Bus	04-10	Rear Axle Only (No Controls)				3482	F/A	6988
		Rear Axle Kit Only -c/w Shock Absorbers (No Controls)				3498	F/A	6988
		Electronic Height Control-With Lowering 				3483	F/A	6988
		2.8 Tonne Vehicle-1540 kg front axle load-4 Corner-Electronic Height Control-With Lowering 	3525	F/A	6988	3525	F/A	6988
		3.2 Tonne Vehicle-1710 kg front axle load-4 Corner-Electronic Height Control-With Lowering 	3526	F/A	6988	3526	F/A	6988

*Notes:*

*+ =Load Sensing Valve kits available-Contact Drive-Rite for further details*

Model	Year	Notes	Front kit	Type	Airspring	Rear Kit	Type	Airspring
Volkswagen (cont.)								
T5 Chassis Cab	04-10	Rear Axle Only (No Controls)				3481	F/A	6988
		Rear Axle Kit Only -c/w Shock Absorbers (No Controls)				3499	F/A	6988
		Electronic Height Control-With Lowering 				3484	F/A	6988
		2.8 Tonne Vehicle-1540 kg front axle load-4 Corner-Electronic Height Control-With Lowering 	3527	F/A	6988	3527	F/A	6988
		3.2 Tonne Vehicle-1710 kg front axle load-4 Corner-Electronic Height Control-With Lowering 	3528	F/A	6988	3528	F/A	6988
T5 Van/ Bus/Chassis	04-10	2.8 Tonne Vehicle-1540 kg front axle load	5506	F/A	6988			
T5 Van/ Bus/Chassis	04-10	3.2 Tonne Vehicle-1710 kg front axle load	5507	F/A	6988			
Model	Year	Notes	Front kit	Type	Airspring	Rear Kit	Type	Airspring
Volvo								
140,160	66-74					4101	C/R	6002
240,260	75-85					4106	C/R	6015
850	90-01					4105	C/R	6013

*Notes:*

*+ =Load Sensing Valve kits available-Contact Drive-Rite for further details*

For vehicles not listed please contact Drive-Rite using the details below



Unit 626 Kilshane Avenue  
North West Business Park  
Ballycoolin  
Dublin 15  
Ireland

Tel: +353 1 8612 632

Fax: +353 1 8612 647

Email: [info@driveriteltd.com](mailto:info@driveriteltd.com)

Web: [www.driveriteltd.com](http://www.driveriteltd.com)

*Notes:*

*+ = Load Sensing Valve kits available - Contact Drive-Rite for further details*